deli

USER MANUAL Barcode Scanner No.14970W



CONTENT

1. Packing List	1
2. How to Use the Barcode Scanner Correctly	1
3. Component Description	2
4. Multi-Mode Switching	2
5. LED Display	3
6. Technical Specifications	4
7. Product Features	4
8. Receiver Installation Method ··· ·· ·· ·· ·· ·· ·· ·· ·· ··	5
9. Basic Settings	5
10. Scanning Mode Settings	5
11. Chinese Character Output Mode	6
12. Function Settings	6
13. Wireless Transmission Pairing Settings	7
14. Decode Alert Beep Settings ··· ·· ·· ·· ·· ·· ·· ·· ··	8
15. Quantity of Electricity Display	9
16. Vibration Alert Settings	9
17. Sleep Time Settings	9
18. Simple Maintenance Methods	10
19. Troubleshooting	10
20. Repair Policy	11

Dear customers , thank you for choosing products. We are committed to providing you with high quality products to ensure best performance, please read this manual carefully before use!

Packing List

Barcode Scanner*1. Base Stand*1. Type-B USB Cable*1.


How to use barcode scanner correctly

1.If the barcode is small, the barcode shall be close to the product scanning window; On the contrary, if the barcode large, the barcode should be slightly away from the produ scanning window, so that it is easier to read the barcode

sconning Wildow, so unto it is expert with the burde correctly.

2. If the borcode has a high reflectance (for example, the burd surface is coated with film), the barcode should be kept at a certain angle with the product scanning window, so that the barcode can be successfully scanned.


3. When scanning the barcode, it must be aligned and the barcode can be must be completely wroped ground the barcode and the same than the completely wroped ground the barcode. scanning line must be completely wrapped around the barcode for decoding. It is not allowed to scan only part of the barcode, otherwise there may be error code.




-1-



Component Description





Multi-Mode Switching


Mode 1Connect the charging pins base to your computer with Type-BLSB cable, ensure successful paining between the barcode scanner and wileless receiver and insert the wireless receiver into the base. Then, the scanner can achieve continuous gover supply through the base and wireless data transmission to the connected computer.



Solution

Mode 2: Connect the barcode scanner directly to a comput the Type-B USB cable for both data transmission and batter charging.





LED Display

It can display signal strength, quantity of electricity and current time Time Adjustment: You can visit our official http://www.nbdeli.com, find the Download Center in After-Sales Service and download the Time Adjustment Software.



Technical Specifications

Battery Capacity	3.7V / 2000mAh Lithium Battery				
Standby Durrent	90mA				
Operating Current	300mA (Typical)				
Scanning Depth	EAN-I3 (litmil): 50-200mm				
Sensor	840+480 CM0S, 120 FPS				
Light Source	White LED / Green LED				
Charging Voltage	SV== IA				
Scanning Types	10 code, 20 code 10: s4mit 20: 275mil				
Scenning Accuracy					
Supported Bercode Types	10 Bascolas: AM-VER, Code ID. Code 98. Code 928. Codebas: Deutsche 12. Deutsche IA. EM-VER, Gode ID. Code 928. Codebas: Deutsche 12. Deutsche IA. EM-VER, GODE IDEN IDEN IDEN IDEN IDEN IDEN IDEN ID				
Operating Temperature	0°C to 46°C				
Storage Temperature	-20°C to 80°C				
Operating Humidity	5% RH to 90% RH (Non-Condensing)				
Alert Methods	Buzzer, LED Indicator, Vibration				
Transmission Types	2.46 Wireless / Bluetooth / Wired (USB)				

Scanning Modes Menual / Auto Product features

1.The built-in storage of this product has the counting function. The building solding and the product has the country function, which can directly carry out some simple dailig counting work. All parameter settings of this product can be completed through borode scanning and soved in the memory of barcode scanner. The inventory content and parameter settings can be retained after the power is turned off. after the power is turned off. 2.It can directly read one-dimensional barcade and two-dimen-sional code on mobile phones and computer screens.

sional code on mobile phones and computer screens.

37this product has a one button politing function, (which can early und autically complete the transmission).

In this product is the computer of the comp

Substituting Mode".

5.Low power consumption, long standby time, built-in 2000mAh lithium battery.

Receiver installation method

1.Plug the wireless receiver into the USB connector of the 2.After the wireless receiver is inserted into the computer, the system will automatically install the driver (if the driver installation falls, please unplug the receiver or restart the computer). 3.After the driver is installed, the receiver can transmit data with the paired scanner.















Reading mode setting







Chinese Character Output Mode

DELI GROUP CO., LTD.

Dell industrial Zone. Ninghal County, Ningbo
City, Zhajlang Province, China Made in China

This barcode scanner supports Chinese character output from QR codes but requires configuration of the output data encoding format. (GBK format is compatible with Notepad and Excel, while UTF-8 format works with Word)

CERTIFICATE







(Scan the following 2 barcodes in sequence) **→ |||||||||**





(Scan the following 2 barcodes in sequence)

Function settings







1.Normal mode: scan the barcode into the normal mode, in which the scanning results will be uploaded to the computer in time (this mode is the default mode). 2.Counting mode: scan the barcode to enter the counting mode, in which the scanning results will be stored in the internal memory (when the internal memory is used up, the buzzer will beep three times for prompt)

-6-

3.Data upload: scanning the barcade can upload the data 3.Just uploads aconning the botcode con upload the data stored in the internal memory to the computer in turn (please ensure that the wireless signal is normal some content of the buzzer will be perfectly the content of the buzzer will be perfectly the total the limited of the buzzer will be perfectly the total to the some store the buzzer will be perfectly the total report of stored data: sconning the barcods will display the total report of stored data: sconning the barcods will display the marker of all stored data the counting mode is applicable). 5.Clear counting data: scanning the barcode will clear all

Wireless Transmission Pairing Settings

I. 2.4G Wireless Receiver Pairing Settings Remove the receiver from the computer or base and first scan the "2.4G



2. Scan the "Receiver Re-pairing Setup Code". At this point, the LED signal



3. Wait until the LFD white signal light flashes rapidly and continuously Within one minute, insert the receiver into the computer or base. A bee sound will confirm successful pairing. The receiver can only be paired with one scanner

IL Bluetooth Wireless Pairing Settings

1. The default Bluetooth name for this scanner is 14970WB HID. First, scan the "Bluetooth HID Wireless Mode Code", then scan the "Bluetooth Pairing Setup Code".



 When the LED green signal light starts flashing rapidly and continuously, within one minute, you should enable Bluetooth on your target device, search for and select "14570WB HID" to connect, You will hear a confirmation beep after successful pairing. The scanner can only maintain one active Bluetooth connection at a time.

Note: When using with mobile devices, we recommend disabling physical keyboard input and text prediction features

III. Bluetooth Mode Data Transfer Speed Settings The default data transfer speed for the scanner in Bluetooth mode is

Note: Due to differences in connected devices, the Bluetooth transfe speed can be set to either "Normal Transfer" or "Low Speed Transfer" to ensure accurate data unload



Decode sound settings





Indicator Description

Indicator	Exploin
The green light is on	The scanning indicator lamp flashes briefly when the barcode is successfully read
The red light is on	If the red light is always on, it means charging if the red light is it means charging is full or not connected
Green light flashing	Pairing status in 248 mode
Green light slow floshing	Module is in upgrade state
LED bottery floshing:	Chorging

-8-

Sound description

Horlding mode	Explain
Along sound	Indicates that the power is on
A short sound	It indicates that the normal barcode is read, or the pairing is successful, or the wireless connection is successful
three short sounds	it indicates that the normal barcode is read, or the pairing is successful or the wireless connection is successful
Five abort sounds and stop scorning	Indicates that the bettery is low (please charge it in time)
two long sounds	Indicates a wireless disconnection
non-short constr	

Power display



Vibrating Alert











Simple maintenance method

I.The dirt and dust on the scanning window sometimes affect the work of the scanner. When cleaning, you should use high-quality factor tissue pose, gently wipe it, and then blow it with a blowing balloon. If the paper with poor quality is used for wiging for a long time, the surface finish of the scanning window will be damaged and the reading effect of the scanner will be affected. will be affected.

2.The shell of the scanner can be wiped with a soft cleaning cloth. If necessary, a small amount of detergent can be added with water, and then wiped with a soft cloth dipped in water.

Troubleshooting

Problem Possible causes

	immediately after power on	power	when charging, and off when fully charged)		
	Barcode data is not uplooded	Scanner and receiver not paired successfully	Please ensure whether the Wreless barcade scanner and receiver are paired (if not, please pair again)		
2		The distance between the barcode scorner and the receiver is too far	Please check whether the wheless bacode scanner has a signal data upload. (If the buzzer beeps' three times in a row, it indicates that the signal is insufficient.) The scanner needs to be close to the receiver or switched to the inventory made.		
		This type of bar code system is not enabled	Open the code system by reading the setting code		
	There is a Loser line, but the borcode connot be read	Bar code is damaged	Please try scanning other barcodes with the same barcode type		
3		improper distance between sconner and barcade	Please move the barcode scanner near or far away from the barcode		
		The height of the boroode scanner is not enough to completely cover the boroode	Read the barcade after aligning it		
	The scanned data is	Input method enor	Convert the input method to the standard English input method		
4	displayed incorrectly on the host	Other settings have been made to the soanner	Restore the scanner parameters to the factory settings, or contact the manufacturer's service center		
5	The barcode characters are garbled or wrang	The keyboard country setting of the barcode scanner does not match the country where the keyboard is used	Set the barcode scanner keyboard country to match the country where the keyboard is used		
6	Other conditions connot be decoded	Device transfer error	Turn off the power supply of the equipment, connect the equipment and the scanner correctly, turn on the power supply of the equipment,		

No power on or Mainly caused Please charge in time to ensure power off by low battery sufficient power (the red light is an

Maintenance

Our company is responsible for free maintenance in case of product failure within one year of normal use from the date of purchase.

The start date of the warranty period is subject to the purchase date and invoice of the product warranty card

Please show the product warranty card and invoice during

Please keep this warranty card properly. If it is lost, it will not be replaced. The purchase date filled in must be consistent with the invoice number otherwise it will be invalid.

This card cannot be altered, otherwise it will be invalid. For products beyond the warranty period or not subject to free maintenance, the maintenance service center of our company is still enthusiastic to serve you.

One of the following conditions does not belong to the scope of I products beyond the warranty nedad

2. Those who cannot provide purchase invoices or valid 3. The appearance is naturally old due to use, and the consume

requires undating

requires updating.

4. Follure caused by follure to use according to the instructions
5. Follure caused by folling or collision.

6. Follure caused the self assembly, disassembly and repair.
7. Samples and processed products for commercial display and products with performance overload test

The table of toxic and hazardous substances/elements and their content

	Hazardous and noxious substance or elements					
Part name	Pb	Hg	Cd	Cr(VI)	PBB	PBDI
Cable	0	0	0	0	0	0
Electronic parts	×	0	0	0	0	0
injection	0	0	0	0	0	0

Declaration

 This product complies with the requirements for Class F general low-power devices as specified in the 'Catalog and Technical Requirements for Short-Range Micro-Power Radio Transmission Equipment.* Operating frequency: 2400–2483.5 MHz, maximum transmit power: 10 mW (e.f.r.p), frequency tolerance: 75 kHz. The product is equipped with a spring antenna. GESK modulation, and an antenna gain of 3.5 dBi.

2 Users shall not modify the usage scenario or conditions, extend the transmission frequency range, increase the transmit power (including adding external RF power amplifiers), or alter the transmission antenna

This product must not cause harmful interference to other lawful radio stations or claim protection against such interference.

4. The product must tolerate interference from industrial, scientific, and medical (ISM) equipment emitting RF energy, as well as interference from other

5. If harmful interference is caused to other lawful radio stations, the user must immediately cease operation and may only resume use after taking measures to eliminate the interference.

6. When using this micro-power device in aircraft or within electromagnetic protection zones—such as radio astronomy observatories, weather radar stations, satellite earth stations (including tracking, telemetry, satelline Burin's succious (including datasing, seelingly, command, and navigation stations), and other military/civillian radio stations or airports—users must comply with electromagnatic environmental protection regulations and relevant industry authorities.

7. The use of any type of model remote controller is prohibited within a 5,000-meter radius centered on an airport runway.

WARRANTY CARD -

Name	Phone		Postcode
Mailing Address			
Product Name	Mod	el	
Date of Purchase			
Province	City/to	own	

REPAIR FORM

* For any question, please contact your local dealer

- 11 -

- 10 -