
THERMAL LABEL PRINTER SER'S MANUAL


MODEL: 740C





1.packing checklist

Please check if the product is intact after unpacking and verify that all the accessories have been received. Please contact the dealer for any defect and/or missing of accessory.




Tips:


1. To download the driver and editing software, please go to Deli's official website; 2.Please use "First page rollback" function indoors and ensure that the printer is not exposed to strong light. If it is, please turn off the "First page rollback" function in the setting menu.


2. Physical appearance and components






top cover release button








3.Loading the paper roll


1. Stand in front of the printer and follow the arrow to open the receipt cover by pushing it up.


2.Hold the paper scroll and take out the paper scroll upwards.




3. In accordance with the inner diameter of the paper roll, load the paper roll into the paper scroll.

4. Load the paper roll set into the printer from top to bottom.






- 5. Pull out part of the paper roll through the paper guide, and close the paper guide according to the paper width to regulate both sides of the paper.
- 6. Press down until you hear a click. Tear off any excess paper in the direction of the cutting blades.



4. Connecting the power cord

- 1. Make sure the printer's power switch is off (0).
- 2. Connect the power adapter to the printer.
- 3. Connect the power cord to the power adapter.
- 4. Plug the power cord into the other end of the power supply.



WARRANTY CARD

Thank you for your purchase of our products. The interests of customers who purchase our products will be protected. For any malfunction due to product quality problems, please contact authorized local dealers or service centers with this receipt and the warranty card.

Warranty terms:

- For product failures occur under normal operating circumstances, free of charge repair and spare parts
 replacement service shall be provided by our company within one year commencing from date of purchase.
- Customers are required to present this warranty card and the original purchase invoice to our company upon request for warranty service. This warranty card shall be valid only after the following form is filled out in details and affixed with official seal of the dealer.
- 3. No free of charge repair service shall be provided in the event of any of the following circumstances:
 - (1) Expiration of the warranty period:
 - (2) Damages caused by improper use, maintenance or storage not in accordance with the requirements of the user manual;
 - (3) Failure or damage resulting from unauthorized disassembly, repair or modification:
 - (4) Failure or damage caused by force majeure:
 - (5) Wear parts or accessories.

This warranty card is being delivered with the product, one card for one product. Please keep this warranty card in proper condition for free warranty service. There is no replacement if lost.

		Date of Purchase:		Y		M D	
Product Information	Product Name			Serial Number			
	Product Model Number			Manufacturing Date			
Customer Information	Company Name				Contact	:	
	Address				Phone		
Sales Information	Dealer Name				Contact		
	Address				Phone		
	Date of Purchase				Invoice No.		
	Description of Malfunction	Maintenance Results	Customer Signature	Maintenance Technician Sig	nature		aintenance ate
Maintenance Record							
		· ·					

This copy shall be cut along the dotted line and kept by the dealer.

Product	Product Name		Serial Number				
Information	Product Model Number			Manufacturing Date			
Customer Company Name					Contact		
Information	Address						
	Dealer Name				Contact		
Sales Information	Address						
	Date of Purchase				Invoice No.		
	Description of Malfunction	Maintenance Results	Customer Signature	Maintenance Technician Sig	nature		aintenance ate
Maintenance Record							

Special Disclaimer:
While information of this manual has been rigorously checked and reviewed,
we still cannot rule out the possibility of spelling mistakes and technical
negligence and/or errors. Such negligence and/or errors will be corrected in
the updated version(s) without further notice. The intellectual property of
this manual belongs to our company, and no organization or individual is
allowed to change the content.

CERTIFICATE
Inspector:
Date of Manufacture:



Youtube videos for using



Deli official website

DELI GROUP CO., LTD.

301 Xuxiake Ave. Ninghai County Ningbo 315600 China Made in China info@nbdeli.com www.deliworld.com



KEEP FOR FUTURE USE

Version: 1.0 Date: 02-2021